

To Program Remote to TV

FACTORY RESET

- 1) Press OK and MUTE until red light is solid
- 2) Enter code and press OK to confirm
- 3) Test code by pressing volume up/down

- a) Please press [HOME] + [0] key for 4 seconds.
- b) The set-up will be initialized as LED blinks 5 times..

Battery Failure Indication

1. Normal usage (above 2.0v) no extra indication
2. Battery level drops down to 2.0v level, 1<sup>st</sup> time, the RCU will indicate with 10 blinks.
3. After the initial 10 blinks, the next indicator will be when a total of 50 accumulated key press have been made (where there is no indication of low power), and then another series of 10 blinks on the 50th key press.
4. After another 50 key press (where there is no indication of low power), on the 50<sup>th</sup>, another series of 10 blinks
5. After another 50 key press (where there is no indication of low power), on the 50<sup>th</sup>, another series of 10 blinks. And so on...
6. When battery is down to 1.8v, it stops working.

TV BRAND	CODE						TV BRAND	CODE					
A MARK	1112	1143					ANAM	0285	1043	1054	1056	1080	1112
A.R.SYSTEMS	0160						ANDERSSON	0110					
ACCURIAN	1036						ANITECH	0277	0232	0219	0185	0120	0074
ACER	0746	0640					ANSONIC	0786	0732	0074			
AD NOTAM	1672						ANTECNO	0064					
ADL	0299						AOC	0568	0016	1116	1363	1112	1616
ADMIRAL	0157	0204	0137	0058	1072	1251	APEX	1572					
	1333						APEX DIGITAL	1006	1724				
ADVENT	1247	1388					AQUAVISION	1573	1574	1686			
ADVENTURA	1002						ARC EN CIEL	0178	0173				
ADYSON	0219	0159					ARCELIK	0124	0086	0085			
AEG	0842	0759	0673	0652	0643	0642	ARDEM	0124	0085				
	0031	0286	0282	0263	0110	0109	ARENA	0124	0006				
	0572	0531	0319				ARGOS	0124					
AFFINITY	1680						ARISTONA	0230	0109	0006			
AG	0282						ASA	0234	0105	0102	0087		
AGFAPHOTO	0579						ASBERG	0232	0185				
AHB TVISIONS	0131						ASORA	0171					
AIOSTAY	0129						ASTAR	1477					
AKAI	0842	0638	0636	0548	0517	0287	ASTROSOUND	0074					
	0280	0279	0275	0155	0140	0132	ASUKA	0149					
	0124	0120	0106	0104	0103	0096	ATLANTIC	0197	0089				
	0092	0074	0026	1116	1248	1404	AUDIOSONIC	0269	0263	0232	0185	0171	0163
	1475	1323	1387	1391	1615			0159	0124	0110	0085	0074	
AKITA	0085						AUDIOVOX	1076	1454	1388			
AKURA	0624	0542	0541	0430	0429	0428	AURORA	0219	0171	0170			
	0174	0171	0086	0074	0064		AUTOVOX	0282	0197	0163	0159	0129	0110
ALBA	0713	0307	0264	0202	0175	0172	AVENTURA	1052					
	0074	0069	0064	0060	0006		AVERA	1761					
ALBATRON	1017						AVION	1441					
ALERON	1028						AVTEX	0830					
ALIEN	0264						AWA	0074					
ALLSTAR	0120	0074					AWATRON	0171					
ALTUS	0124						AXESS	1711					
AMERICA ACTION	1043						AXION	1039					
AMPRO	1073						AXXION	0726	0724	0698	0628	0546	
AMSTRAD	0286	0171	0157	0110	0074	0025	BAIER	0751					

BAIRD	0750	0733	0578	0524	0188	0014	CITIZEN	1116	1002	1003	1363	1043	1258
BANG & OLUFSEN	0239	0204						1143					
BASIC LINE	0277	0264	0170	0120	0074	0014	CLARION	1043					
BAUR	0233	0217	0212	0211	0171	0132	CLARIVOX	0258	0232	0161			
	0026	0131	0120	0096	0092	0074	CLASSIC	1043					
	0040						CLATRONIC	0742	0294	0286	0282	0260	0255
BEKO	0690	0510	0263	0255	0225	0195		0232	0129	0124	0110	0074	0064
	0130	0124	0110	0086	0085	0026		0185	0171	0165	0159	0149	
BELCOR	1116						CLP CLASSIC	1333					
BELL&HOWELL	1333	1072					CMX	0770	0763	0591	0589		
BELSON	0741	0685	0230				COBY	1640	1641	1671	1363		
BELSTAR	0110						COLORTYME	1116					
BENQ	1600						CONCERTO	1363					
BEST	0282						CONCIERGE	1073					
BESTAR	0086	0074					CONDOR	0260	0255	0232	0229	0171	0149
BLACK DIAMOND	0120	0074						0109					
BLACK PANTHER	0185						CONIC	0219					
BLAUPUNKT	0528	0096	0092	0091	0006		CONRAC	0225					
BLUE SKY	0286	0282	0273	0264	0172	0124	CONTEC	0277	0171	1043	1050	1051	
	0109						CONTI	0263	0124				
BLUESTAR	0074	0063					CONTINENTAL	0172					
BLUSENS	0787	0654	0611				CONTINU-US	1161	1746	1747			
BOMANN	0282						CORNEA	1116					
BONDSTEC	0163						CORONADO	1143					
BRADFORD	1043						COSMOS	0074					
BRANDT	0270	0195	0193	0178	0173		CRAIG	1043	1054				
BRIONVEGA	0204	0157					CROSLY	0232	0204	0165	0148	1164	
BROCKWOOD	1116						CROWN	0764	0286	0282	0274	0264	0263
BROKSONIC	0285							0255	0232	0185	0171	0129	0124
BRUNS	0204							0086	0085	0074	0063	1043	1143
BSR	0129						CS-ELECTRONICS	0163	0159	0064			
BUSH	0836	0766	0725	0568	0501	0314	CURTIS	0260	0074				
	0303	0287	0286	0283	0264	0232	CURTIS MATHES	1116	1258	1363	1143		
	0202	0129	0124	0115	0110	0074	CXC	1043					
	0069	0063	0031				CYBERHOME	1015					
BYDESIGN	1031	1032					DAEWOO	0720	0598	0540	0519	0431	0269
CAMPER	0085							0170	0120	0074	1363	1043	1076
CANDLE	1116	1002	1003	1363				1143					
CELEBRITY	1001						DANSAI	0219					
CELLO	0536	0434	0318	0315	0312	0311	DANTAX	0124	0074				
	0310	0301					DAYTEK	0194					
CENTURION	1116						DAYTRON	1363					
CENTURY	0204	0165					DE GRAAF	0132					
CETRONIC	1043						DECCA	0189	0184	0161	0159	0128	0074
CGE	0260	0232	0165	0129				0069	0066	0063			
CGM	0264	0086	0085	0074			DELL	1320	1164	1363	1618		
CHANGHONG	0717	1247					DELTON	0074					
CIE	0171	0170	0163	0074	0064	0025	DENVER	0638	0625	0596	0527	0282	0171
CIELO	1714							0074					
CIIL	1732						DESMET	0074					
CINERAL	0272						DGM	0543	0426				
CINEX	0294	0031					DIBOSS	0621					



GO VIDEO	1026						HIFIVOX	0178	0173						
GOLDFUNK	0264	0074					HIMITSU	1043							
GOLDHAND	0171	0159					HINARI	0224	0171	0129	0074	0064			
GOLDLINE	0273						HISAWA	0273							
GOLDSTAR	0288	0268	0263	0237	0219	0191	HISENSE	0129	0451	0828	0813	0798	0752		
	0171	0163	0159	0129	0124	0110		0597	0551	0302	1419	1442	1619		
	0038	1113	1116	1102	1363	1112		1363	1752	1630					
	0074	1143					HIT	0204							
GOODING	0172						HITACHI	0744	0659	0581	0515	0286	0279		
GOODMANS	0543	0528	0321	0316	0306	0305		0276	0269	0219	0193	0189	0186		
	0287	0286	0285	0275	0270	0269		0173	0161	0159	0140	0132	0129		
	0268	0264	0225	0224	0195	0194		0128	0120	0114	0110	0104	0029		
	0187	0176	0171	0170	0159	0124		0057	0054	0040	0023	0022	1011		
	0120	0115	0110	0109	0103	0074		1166	1009	1143	1072	1363			
	0064	0063	0031	0008				1250	1613	1670	1749				
GORENJE	0286	0274	0110	0086			HITSU	0273							
GPM	0064						HL	0195	0120	0074					
GPX	1674						HOHER	0124	0110	0069					
GRADIENTE	0038						HOSHAI	0264							
GRAETZ	0263	0172	0148	0132	0124	0074	HP	1421							
GRAN PRIX	0791	0734	0696	0294	0031	0006	HUMAX	0576	1518						
GRANADA	0270	0224	0208	0195	0189	0184	HYPER	0171	0163	0159					
	0167	0159	0140	0132	0128	0120	HYPSON	0264	0263	0162	0124	0118	0113		
	0109	0105	0104	0103	0086	0085		0074	0069	0063					
	0081	0078	0075	0054	0043		HYUNDAI	0317	0235	0180	0155	0152			
	0029	0026	0022				IBERVISAO	0129							
GRANDIN	0273	0069					ICE	0171	0159	0074	0064				
GREAT WALL	0074						IDEAL	0264							
GRUNDIG	0690	0552	0527	0510	0287	0232	I-JOY	0543							
	0210	0202	0194	0187	0172	0155	ILO	1472	1399						
	0130	0124	0110	0096	0094	0092	IMPERIAL	0260	0255	0232	0229	0165	0154		
	0091	0073	0069	0063	0031			0129	0110	0109					
GRUNKEL	0785	0732	0543				INFINITY	1164							
GRUNPY	1028	1043					INFOCUS	1333	1230	1547	1548	1470	1532		
H&E	0282							1595	1733	1726					
HAIER	0733	0501	0313	1363	1501	1623	INGELEN	0279	0273	0148	0132				
	1749						INGERSOLL	0171							
HALL MARK	1363						INITIAL	1282							
HANNSPREE	0706	0602	1349	1381			INNO HIT	0237	0189	0161	0159	0074	0006		
HANSEATIC	0308	0277	0269	0229	0225	0220	INSIGNIA	1350	1400	1052	1164	1403	1454		
	0191	0171	0149	0132	0124	0120		1457	1604	1617					
	0110	0092	0085	0060			INTEQ	1073							
HANTAREX	0161						INTERCORD	0233							
HANTOR	0159						INTERFUNK	0265	0255	0178	0165	0148	0137		
HARLEY DAVIDSON	1028							0132	0120	0074	0067				
HARVARD	1043						INTERVISION	0191	0163	0132	0086	0085	0074		
HARWA	0076						IPOSTAR	0171							
HB	0282						IRRADIO	0264	0237	0163	0074				
HB INGELLEN	0172						IRT	0439	0437	0283					
HCM	0277	0171	0159	0074			ISKRA	0085							
HELLO KITTY	1076						ITC	0159	0129						

							LENOIR	0264	0074						
ITL	0171						LENUSS	0837							
ITS	0171	0159	0064				LEVEL	0612	0425						
ITT	0576	0268	0148	0140	0132	0124	LG	0501	0592	0511	0288	0286	0283		
	0110	0031	0014					0263	0181	0124	0110	0069	0038		
JANEIL	1002							0015	0014	0013	1363	1113	1116		
JAY-TECH	0761							1741	1102	1112	1143	1569	1284	1648	
JBL	1164						LIESENKOETTER	0074							
JCB	1001						LIFETEC	0264	0171	0170	0118	0113	0074		
JCPENNEY	1024	1116	1008	1009	1030	1065		0064	0006						
	1258	1143	1333	1363			LITEON	1268							
JETPOINT	0268						LODGENET	1072							
JMB	0063						LOEWE	0608	0204	0142	0131	1164	1738		
JOCEL	0283	0282	0074	0069			LOGIK	0800	0799	0680	0630	0606	0587		
JTC	0850	0807	0761					0531	0264	0187	0070	1072			
JVC	0604	0588	0575	0278	0169	0120	LUMA	0229	0197	0157	0137	0074			
	1038	1034	1001	1210	1581	1639	LUMATRON	0229	0157	0074					
	1668						LUXMAN	1363							
KAIDO	0129						LUXOR	0279	0276	0275	0237	0232	0186		
KAISUI	0280	0273	0074	0006				0159	0148	0140	0132	0128	0120		
KAMACROWN	0064							0110	0105	0104	0103	0074	0066	0014	
KAPSCH	0197	0148	0132	0089			LXI	1166	1007	1138	1052	1251	1333		
KARCHER	0289	0282	0274	0273	0185	0124		1164							
	0110	0109	0074	0031			M ELECTRONIC	0276	0140	0120	0105	0104	0103		
KATHREIN	0187						M.D.C.	0074							
KAWASHO	1116	1001					MACROLUX	0069							
KEC	1043						MAGNADYNE	0204	0185	0163	0161	0148	0074		
KENDO	0273	0270	0229	0157	0137	0124	MAGNAFON	0199	0185	0161					
	0074	0060	0006				MAGNASONIC	0074							
KENMARK	0831	0803					MAGNAVOX	0120	1164	1116	1003	1363	1333		
KENNEDY	0197	0148						1226	1390	1467	1431	1594			
KENNEX	0264	0074					MAGNUM	0294	0263	0124	0074	0031			
KENWOOD	1116	1001					MAJESTIC	1333	1072						
KEYMAT	0235	0207					MANHATTAN	0264	0074						
KIOTO	0439	0436	0283	0228			MANTA	0821							
KITON	0264	0113					MARANTZ	0074	1116	1164	1281				
KLEGG	1466						MARSHAL	0064							
KLOSS	1002						MASCOM	0279	0074	0031					
KMC	1143						MASTERS	0074							
KNEISSEL	0273	0264	0229	0074	0058		MATSUI	0587	0202	0196	0172	0171	0159		
KNOLL SYSTEMS	1230	1659						0070	0154	0129	0124	0110	0096	0074	
KOERTING	0274	0204	0086					1164	0069	0063	0062	0060	0025	0014	
KOGAN	0579						MATSUSHITA	1080							
KONKA	1457						MAXELL	0074							
KREISEN	1530						MAXENT	1242							
KTV	1043	1116	1143	1154			MAXIM	0031							
KUBA ELECTRONIC	0233	0132					MEDION	0779	0771	0745	0726	0722	0699		
KURAZAI	1072							0683	0570	0560	0287	0283	0279		
LAZER	0074							0225	0194	0187	0124	0120	0113		
LECSO	0110							0264	0110	0074	0031				
LENCO	0689	0682	0628	0593	0579	0546	MEGAS	0273							
	0170	0110					MEGASAT	0726							

MEGATRON	1116	1011						NIKE	0074						
MEMOREX	1007	1072	1363					NIKEI	1043						
MEMORY	0286							NIKKAI	0219						
MERRIT	0132							NIKKEI	0264	0074					
METEOR	0185							NIKKO	0074	1116					
METZ	0794	0793	0736	0265	0264	0254		NIKO	1527						
	0219	0096	0092	0074				NISSAN	0268						
	0140	0132	0120	0106	0105	0104		NOBLIKO	0232	0185					
	0102	0074	0014	0103				NOGAMATIC	0178	0173					
MGA	1116	1363	1024	1028				NOKIA	0653	0645	0527	0279	0276	0275	
MICROMAXX	0282	0264	0124	0113	0074				0148	0074	1116	1003	1164	1363	
MIDLAND	1333	1073							1056	1024					
MIKOMI	0516	0286						NORCENT	1390						
MINERVA	0232	0172	0096	0092				NORDMENDE	0651	0518	0282	0270	0261	0195	
MINUTZ	1008								0193	0178	0173	0132	0129	0124	
MIRAI	0582								0069	0074					
MISAKAI	1052							NORDWAY	0129						
MITSAI	0110							NORM N	0074						
MITSUBISHI	0224	0204	0120	0096	0077	0076		NORTEK	0264	0074					
	0075	0074	0071	1109	1024	1028		NOVA	0087						
	1348	1450	1658	1363				NOVATRONIC	0074						
MIVAR	0781	0262	0259	0232	0223	0209		NUVISION	1351	1567					
	0161	0159						OCEANIC	0276	0140	0132	0104	0103	0014	
MMC2	0001							ODYS	0727	0697	0656	0647	0642	0628	
MONIVISION	1017								0610	0543	0531	0528	0525	0519	
MONTGOMERY WARD	1333	1072						OKANO	0255	0074					
MORAVA	0152	0131	0109					OLEVIA	1432	1363	1333				
MOSAIC	0264	0074						ONKING	1043						
MOTOROLA	1081							ONWA	0280	0074	0064	1043			
MT LOGIC	0773	0718	0543	0124				OPERA	0124						
MTC	0132	0131	0086	1116	1363	1258		OPTOMA	1265	1249					
MULTITEC	0264	0074						OPTONICA	1019	1251					
MULTITECH	0232	0185	0171	0159	0129	0085		ORAVA	0074						
	0074	0031	1043					ORBITER	0086						
MURPHY	0536	0232						ORION	0760	0662	0515	0507	0236	0219	
MURYUANA	0120								0205	0202	0196	0194	0187	0185	
NAD	1138								0162	0129	0124	0120	0118	0074	
NAKIMURA	0170								0070	0069	0064	0063	0062	0059	
NAONIS	0137							ORION (H)	0228	0110	0074	0062	0060	0025	
NEC	1272	1197	1116	1024	1056	1019		ORMOND	0074						
	1262	1236	1281	1575	1717	1758		OSAKI	0074						
NECKERMANN	0274	0255	0233	0217	0212	0211		OTAKE	0196	0129	0060	0059			
	0204	0169	0159	0157	0137	0132		OTF	0282	0204	0074				
	0124	0120	0118	0096	0092	0081		OTTO-VERSAND	0277	0270	0269	0233	0230	0217	
	0074	0060	0059	0043	0026				0212	0211	0205	0202	0195	0193	
NEI	0074	0064							0171	0167	0163	0159	0152	0149	
NET TV	1242								0132	0131	0124	0120	0118	0110	
NEUFUNK	0124	0109							0092	0081	0074	0069	0063	0060	
NEX	0316								0185	0096	0059	0040	0026		
NEXIUS	0282							OVP	0074						
NEXUS	1620	1454						PACIFIC	0236	0124	0109	0063			

PALLADIUM	0276	0260	0255	0229	0171	0165	PROVISION	0282	0120	0109	0066				
							PROX	1572							
	0161	0157	0137	0132	0124	0118	PULSAR	1116	1073						
	0031	0006	0113				PYE	0120	0109						
PANASONIC	0595	0513	0851	0740	0639	0254	PYLE HOME	1661	1662						
	0167	0148	1080	1034	1056	1164	QMEDIA	0728	0676	0579	0528				
	1552	1524	1607	1664	1208		QUADRO	0286	0113	0110					
PATHE CINEMA	0129						QUASAR	1034	1056						
PATHE MARCONI	0178	0173					QUELLE	0261	0257	0255	0237	0234	0232		
PEAQ	0668							0229	0221	0219	0217	0212	0211		
PEERLESS-AV	1723	1763						0205	0204	0197	0195	0185	0171		
PHILCO	0260	0255	0232	0204	0165	0154		0169	0167	0165	0163	0159	0157		
	1056	1024						0142	0140	0132	0131	0120	0118		
PHILIPS	0230	0811	0810	0570	0802	0120		0110	0105	0102	0096	0092	0088		
	0110	0109	0092	0069	0067	0021		0087	0086	0074	0071	0060	0059		
	0014	0009	0008	1164	1038	1116		0043	0025	0026	0040				
	0019	1003	1363	1206	1431	1333	RADIO SHACK	1019	1363	1143	1043				
	1727	1161	1594				RADIOLA	0120	0074	0067					
PHOCUS	0225	0130	0124	0110			RADIOMARELLI	0163	0161	0074					
PHOENIX	0110						RADIONETTE	0181							
PILOT	1116						RADIOTONE	0294	0171	0085	0074				
PIONEER	0193	0132	0074	1234	1116	1393	RANK	0232							
	1272	1520	1660				RCA	1333	1065	1116	1363	1024	1056		
PIONIER	0074							1161	1588	1713	1751				
PLANAR	1728	1742					REALISTIC	1007	1019	1043					
PLAYSONIC	0124	0074					RECCO	0283							
POLAROID	0404	0402	0401	0314	1388	1323	RECOR	0074							
	1328	1353	1354	1355	1356	1494	REDIFFUSION	0132							
	1387	1391	1505	1506	1508	1526	REDSTAR	0282							
PORTLAND	1363	1143					REFLEX	0264	0113						
POWERPOINT	0172						REFLEXION	0596	0543						
PRANDONI	0069	0066					REOC	0124							
PRANDONI-PRINCE	0161	0137					REVOLUTION HD	1466							
PREMIER	0069						REVOX	0131							
PRIMA	0219						REX	0197	0163	0157	0137	0129	0089		
PRIME	0697	0074						0088							
PRIMUS	0120						RFT	0204	0132	0110	0085	0064			
PRINCETON	1004						RM 2000	0264	0074						
PRISM	1034						ROADSTAR	0286	0280	0264	0263	0129	0124		
PRO 2	0031							0120	0110	0063	0069				
PROFEX	0232	0171	0129				ROBOTRON	0204							
PROFILO	0294	0074	0031				ROSITA	0171							
PROFITRONIC	0185	0074					ROWA	0283	0074						
PROLINE	0803	0286	0285	0270	0269	0229	ROYAL	0277							
	0205	0189	0128	0120	0109		ROYAL LUX	0282							
PROSCAN	1333	1722					RUNCO	1073	1395	1416	1072	1697			
PROSONIC	0637	0636	0625				SABA	0270	0195	0193	0178	0173	0161		
PROTECH	0264	0219	0074					0148	0132	0074					
PROTON	1363	1112	1143	1528			SAGEM	0273	0206						
PROTRON	1392	1398	1498	1499	1500		SAISHO	0205	0159	0129	0070	0060	0069		
PROVIEW	1494							0025							

SAIVOD	0786						SHENG CHIA	1081										
SAKIO	0171						SHERWOOD	1349										
SALORA	0751	0730	0698	0579	0543	0535	SHINTOM	0074										
	0279	0276	0275	0237	0159	0140	SHINTOSHI	0074										
	0137	0132	0128	0120	0110	0105	SHIVAKI	0264	0129	0074								
	0104	0103	0074	0066	0014		SHOGUN	1116										
SAMBERS	0232	0185	0161				SIAREM	0204	0185	0161	0148							
SAMPO	1116	1363	1242				SIEMENS	0554	0294	0221	0219	0096	0092					
SAMSUNG	0505	0601	0506	0284	0268	0257		0074										
	0237	0220	0171	0159	0086	0074	SIERA	0069										
	0026	0008	1258	1050	1363	1143	SIGNATURE	1072										
	1333	1228	1229	1655			SILO	1001										
SAMSUX	1116						SILVA	0129										
SANKYO	0074						SILVA SCHNEIDER	0597	0294	0286	0282	0110	0031					
SANSEI	1076						SILVER	0277	0224	0171	0074	0064						
SANSUI	0264	0074	1400	1615	1454	1762	SILVERCREST	0779										
SANY	0193						SIM2	0226	1205									
SANYO	0286	0221	0189	0159	0110	0087	SIMPSON	1003										
	0086	0074	0052	0014	1007	1166	SINGER	0204	0185	0163	0120	0074	0069					
	1057	1187	1657	1750			SINUDYNE	0282	0212	0204	0196	0185	0162					
SCEPTRE	1276	1699						0148	0120	0118	0074	0069	0063					
SCHAUB LORENZ	0537	0531	0277	0275	0264	0171		0062	0025									
	0148	0132	0124	0074			SKY	0207	0194	0187								
SCHNEIDER	0702	0621	0324	0282	0269	0264	SKYVUE	1648										
	0233	0163	0159	0152	0132	0124	SLX	0264										
	0120	0110	0088	0074	0069	0064	0063	SMARAGD	0172									
SCHNEIDER (F)	0120	0067						SOLAVOX	0129									
SCOTCH	1116						SONITRON	0159										
SCOTT	0638	0593	0548	1028	1043	1048	SONIX	0194										
	1143	1363	1497				SONOKO	0074										
SEARS	1030	1363	1007	1028	1057	1143	SONOLOR	0140	0129									
	1333	1166	1138				SONTEC	0074										
SEELVER	0069						SONY	0211	0217	0212	0071	1001	1651					
SEG	0756	0645	0579	0560	0559	0543	SOUNDCOLOR	0264	0074									
	0517	0286	0269	0264	0232	0219	SOUNDESIGN	1028	1363	1003	1043							
	0185	0171	0165	0159	0129	0115	SOVA	1041										
	0113	0110	0064				SOXO	0543										
SEIKI	1690						SOYO	1528										
SEITECH	0282						SPECTRA	0170										
SELECO	0229	0226	0197	0195	0157	0137	SPECTRICON	1112										
	0129	0120	0110	0109	0089	0088	SPECTRONIQ	1499	1500									
	1205	1011					SQUAREVIEW	1052										
SELECT	0264						SSS	1363	1043									
SENCOR	0110						STANDARD	0074										
SENTRA	0129	0064	0026				STARLITE	0264	0171	0074	1043							
SERINO	0273						STARLUX	0171										
SET	0074						STARS	0120										
SEURA	1704						STERN	0229	0197	0157	0137	0129	0089					
SHARP	0714	0556	0513	0568	0528	0507		0088										
	0432	0224	0171	0081	0073	1251	STRONG	0286	0115	0110								
	1019	1028	1363	1143	1684	1692	1735	SUNBRITE	1633	1634	1635	1386						



SUNGOO	0672							TELERENT	0233	0131	1072						
SUNKAI	0273							TELESTAR	0294	0282	0227	0074	0031				
SUNSTAR	0171	0074						TELETECH	0264	0171	0165	0074					
SUNSTECH	0546							TELETON	0197	0159	0132	0089	0088				
SUPERIOR	0286							TELEVIEW	0031								
SUPERSCAN	1052	1081						TELRA	0294	0074	0031						
SUPERTECH	0171	0129	0074					TENSAI	0264	0191	0171	0159	0149	0129			
SUPRA	1116								0120	0110	0064						
SUPRATECH	0670	0619						TENSON	0171								
SUPRE MACY	1002							TESLA	0282	0273	0264	0263	0229	0204			
SUPREMA	0273								0160	0131	0129	0124	0110	0109			
SUPREME	1001								0074	0069	0006						
SVA	1328							TEVION	0771	0560	0531	0294	0287	0264			
SWISSTEC	0704	0603	0574	0309	0207	0194			0225	0124	0074	0006					
	0187							THOMSON	1049	1055							
SYLVANIA	1116	1003	1052	1164	1333	1514		THOMSON (TCL)	0668	0564	0562	0561	0270	0261			
	1593								0195	0193	0178	0173	0152	0132			
SYMPHONIC	1052							THOMSON IR2000	0006	0001							
SYNTAX OLEVIA	1432	1363	1333					THOMSON REC 80	0011	0010	0008						
TADISTAR	0074							THORN	0270	0232	0224	0212	0211	0201			
TANDBERG	0254	0173	0157						0200	0199	0198	0195	0189	0188			
TANDY	1251								0178	0177	0170	0169	0167	0161			
TASHIKO	0224	0159							0160	0159	0132	0128	0120	0110			
TATUNG	0286	0282	0189	0184	0161	0159			0107	0106	0105	0102	0096	0087			
	0128	0118	0070	0069	0066	0063	1056		0078	0075	0071	0067	0052	0043			
TAURAS	0751	0282							0022	0026	0014						
TCL	1705	1749						THORN-FERGUSON	0200	0198	0195	0188	0160				
TCM	0006							TILEVISION	1663								
TD DESIGN	0140	0131						TMK	1363								
TEAC	0584							TNCI	1073								
TEC	0264	0171	0170	0165	0159	0129		TOBO	0171								
	0074							TOKYO	0268								
TECHLINE	0264	0185	0113	0110				TOPLINE	0264	0074							
TECHNICA	0286	0282	0074					TOPVISION	0085								
TECHNICS	1034	1080						TOSHIBA	0520	0729	0513	0531	0769	0284			
TECHNIKA	0715	0584							0268	0232	0208	0203	0202	0124			
TECHNISAT	0694	0571	0118	0110					0092	0074	0063	0043	0026	1138			
TECHNOL ACE	1028								1030	1007	1258	1325	1230	1703			
TECHVIEW	1045							TOSUMI	0124								
TECHWOOD	0115	0110	1363					TOTEVISION	1143								
TECNIMAGEN	0120	0069						TOWADA	0185	0129							
TECNISON	0171	0159	0074					TRANS-CONTINENTS	0069								
TECSONIC	0074							TRILUX	0292	0264	0120						
TEKNIKA	1002	1003	1363	1024	1028	1043		TRISTAR	0064								
	1072	1258	1143					TRIUMPH	0234	0219	0025						
TEKON	0268	0171						TVE	0074								
TELEAVIA	0178	0173						TWF	0320								
TELEFUNKEN	0638	0530	0517	0270	0261	0225		UHER	0233	0197	0185	0149	0131	0089			
	0195	0193	0178	0177	1037	1046		ULTRAVOX	0204	0185	0163	0148	0074				
	1615							UMC	0801	0715	0704	0606	0603	0584			
TELEOPTA	0171								0579	0528							

