



CFS

CUSTOMER FIRST SATELLITE

Inc.

****Note:** In order to program the RC71H remote control; Press and hold “Select” & “Mute” keys for 3 seconds (until the visible green LED blinks twice) → Press the first digit of the code → wait for 2 green LED blinks → press the rest of the code. If a valid code has been entered, the green LED will blink twice.



Setup Codes For Television (T)

Aaxa 13634	Axon 11937	CTX 10700	11911, 11913, 11944, 11963, 12183, 13559
Acer 11339	Bang & Olufsen 11620	Curtis 12397, 11326, 12352, 12466, 12855, 12859, 13228, 13577, 13636, 13895, 13939	Emprex 11422, 11765
Admiral 10093, 10463, 10179	Bell & Howell 10154	Curtis Mathes 10702, 10054, 10093, 10060, 10047, 10154, 10451, 10145, 11661, 11347, 11959	Envision 11589, 12087, 11365, 12014
Advent 11570	BenQ 11756, 11315, 11562	CXC 10180	Epson 11122
Affinity 13577, 13716, 13717	Berkshire 10047	Cytron 11326	ESA 10171, 11595, 11944, 11963
Aiwa 11362, 11916	Bradford 10180	Daewoo 10154, 10451, 11661, 10623, 10661, 10672, 13115	Fisher 10154, 11362
Akai 10702, 11675, 10765, 10672, 11207, 11385, 11688, 11690, 11692, 11903, 11935, 12232	Broksonic 10463, 11911, 11935, 11938	Dell 11264, 11863	Fluid 12964
Akura 11498	Byd:sign 11311	Denon 10145	Fujimaro 11498
Alaron 10179	Candle 10186	Digital Lifestyles 11765, 11822	Fujitsu 10809, 10179, 10186, 10853
Albatron 10700	Carver 10054	Disney 11665, 11892	Fujitsu Siemens 10809
America Action 10180	CCE 10623	Dumont 10017	Funai 11394, 10171, 10180, 10179, 11271, 11904, 11913, 11963
Anam 10180	Celera 10765	Durabrand 10178, 10171, 10463, 10180, 11463, 11570, 11595, 11665	Futuretech 10180
AOC 11589, 12087, 11089, 11365, 11590, 12014, 12402, 12621, 13707	Champion 11362	Dynex 12049, 11463, 12184	Gateway 11756, 11755
Aomni 11623	Changhong 10765	Electric Mirror 13166	GE 11447, 10178, 10047, 10051, 10451, 10765, 11347, 11547, 11917
Apex Digital 12397, 10748, 10765, 10890, 11217, 11943	Citizen 10060, 10186, 11672, 11935	Electrograph 11755, 11623	GFM 11864, 11886, 10171, 11665, 11963
Astar 11531	Clarion 10180	Electrohome 10463, 11570, 11670, 11672	Gibraltar 10017
Asus 13340	Claris 13807	Electron 12855	GoldStar 10178
Audiosonic 11675	Coby 13478, 13646, 13629, 13627, 13493, 13202, 12560, 12348, 12347, 12344, 12340, 12338, 12326, 12315, 12314, 12306, 12017, 11634, 11538	Element 11886, 12183, 12964, 13559	GPX 10179, 12617, 12784, 13402
Audiovox 11564, 10451, 10180, 13410, 13065, 12513, 12413, 12121, 11951, 11937, 11868, 11865, 11769, 11766, 11276, 10875, 10846, 10802, 10623	Commercial Solutions 11447, 10047	Elite 13867	Grunpy 10180, 10179
Auria 12087, 12277	Conia 11498	Emerson 11864, 11394, 11886, 10178, 10171, 10154, 10451, 10463, 10180, 11661, 11595, 11665, 10623, 10179,	H & B 11366
Aventura 10171	Contec 10180		Haier 11753, 11749, 11748, 11570, 12293, 12309, 12494, 12690, 13204, 13382
	Cornea 13677		Hallmark 10178
	Craig 10180, 13423		
	Crosley 10054, 13115		
	Crown 10180		

Hanns.G 11783
Hannspree 11348, 11351, 11352, 11745, 11783, 12786
Harley Davidson 10179, 11904
Harman/Kardon 10054
Harvard 10180
Havermly 10093
Helios 10865
Hello Kitty 10451
Hewlett Packard 11642, 11494, 11089, 13126
Hidear 13817
Hisense 10748, 11314, 11660, 12183, 13519
Hitachi 11643, 10145, 10679, 10797, 11484, 11576, 11904, 12207, 12756
Hyundai 11219, 13418
iLo 11394, 11463, 11286, 11603, 11665, 11684, 11990, 13149
Infinity 10054
InFocus 11366
Initial 11603, 11990
Insignia 12049, 11423, 11564, 10171, 10463, 12751, 12432, 12417, 12184, 12088, 12002, 11963, 11892, 11660, 11641, 11517, 11385, 11326, 11204
Inteq 10017
iRIS 12189
iSymphony 13094, 13118, 13382
JBL 10054
JCM 12189, 12256
Jensen 11299, 11326, 12541, 13204
JVC 11601, 12271, 12264, 10650, 11774, 10463, 10731, 11253, 11352, 11670, 11923, 12321, 13650, 13854
KDS 11498
KEC 10180
Kingston 13284
Klegg 11366
KLH 10765
Konka 11385
Kost 11483
KTV 10180
Lasonic 13198
LG 11423, 12358, 12731, 12424, 12834, 10178, 10017, 11265, 10700, 12612, 12864, 13941
Lloyd's 11904
LodgingStar 13147
LXI 10156, 10054, 10178, 10047, 10154
MAG 11498
Magnasonic 11913
Magnavox 11867, 11454, 11455, 12597, 12372, 11755, 10054, 10171, 10051, 10706, 13292, 12492, 10179, 11990, 11963, 11944, 11931, 11913, 11904, 10186, 11856, 10230, 10802, 11365, 11198, 11054, 11012
Marantz 11454, 10054, 10704, 11054, 11154, 11398, 11714
Matsushita 10250, 10650
Maxent 11755, 11714, 11757
MB Quart 11868
Megapower 10700
Megatron 10178, 10145
Memorex 10178, 10154, 10463, 10150, 10179, 11570, 11665, 11670, 11892,

11903, 11911, 11924, 11927, 11938, 12739
MGA 10178, 10150
Midland 10047, 10017, 10051
Mintek 11603, 11990
Mitsubishi 11250, 10093, 10178, 10150, 11797, 11917
Monivision 10700
Motorola 10093
MTC 10060
Multitech 10180
Mx Onda 11498
NAD 10156, 11156, 10178
Naxa 12104, 12735, 13154, 13382
NEC 10704, 11398, 11704, 11797, 12293, 13257
NetTV 11755
Nexus Electronics 12183
Nikko 10178
Nimbro 12104
Norcent 11589, 10748, 11089, 11365, 11590, 11591, 11745
Norwood Micro 11286
NuVision 11657, 12158
Ölevia 11610, 11144, 11240, 11331
Onwa 10180
Optimus 10250, 10650, 10154, 11913, 11924, 11927
Optique 12189
Optoma 11348
Optonica 10093
Orion 10463, 11463, 10179, 11911, 11938, 13540
Otic 11498
Panasonic 11480, 10250, 11291, 12264, 10650, 10051, 11271, 11924, 11927, 11941, 11946, 11947, 12240, 12654
PARK 11376, 12104, 12194, 12202
Penney 10156, 10178, 10060, 10047, 10051, 11347
Philco 11394, 10054, 10171, 10179, 11271, 11665, 11963
Philips 11867, 11454, 11455, 11744, 12597, 12372, 11394, 10054, 10171, 13565, 13292, 12740, 12665, 12652, 12492, 11990, 11961, 11944, 11856, 11483, 11365, 11154, 11054, 11012, 10230
Pioneer 11457, 10679, 11260, 11398, 12240, 13254
Planar 11589
Polaroid 11523, 11498, 10765, 11276, 11286, 11314, 11316, 11326, 11385, 10865, 11538, 11762, 11766, 11767, 11769, 11826, 12002, 12121
Portland 10451, 11661
Power Acoustik 11865
Prima 11753, 11749
Princeton 10700
Prism 10051
Proscan 11447, 10047, 11347, 12147, 12183, 12256, 13382, 13577, 13717
Proton 10178
Proview 11498
Pulsar 10017
Pyle 12196, 12641

Quasar 10250, 11291, 10650, 10051, 11924, 11927
RadioShack 10178, 10047, 10154, 10180, 11904
RCA 11447, 12434, 12746, 12932, 12187, 10093, 10047, 10051, 11661, 13938, 13717, 13577, 13382, 13147, 12855, 12183, 12002, 11959, 11958, 11917, 11868, 11781, 11547, 11385, 11347, 10679, 10090
Realistic 10178, 10154, 10180
RevolutionHD 11623
Runco 10017, 11398
Sampo 11755
Samsung 10702, 10650, 10178, 10060, 10766, 10814, 11060, 11235, 11267, 11903, 11959, 12596, 12733, 12814
Sansui 10171, 10463, 11463, 11409, 11670, 11892, 11904, 11911, 11935, 11938, 13540, 13564
Sanyo 11142, 10054, 10154, 10088, 11362
Sceptre 10878, 11217, 11360, 11599, 12337, 12506, 12528
Scotch 10178
Scott 10178, 10180, 10179, 11711
Sears 10156, 10054, 10178, 10047, 10171, 10154, 10179, 11904
Seiki 10178, 12964, 13559, 13560, 13953
Seleco 11351
Sens 11865
Sharp 12360, 10818, 10093, 11393, 11917, 12402, 13867
Sheng Chia 10093
Sherwood 11399, 13061
Sigmac 13423, 13477
Signature 10054
Silo Digital 13794
Simpson 10186
Skyworth 11799, 13253
Solé 11366, 11483, 11623
Sony 11300, 11317, 11685, 11786, 11791, 11904, 12736
Soundesign 10178, 10180, 10179, 10186
Soyo 11520, 11826
Spectroniq 11498
Squareview 10171
SSS 10180
Starlite 10180
SunBriteTV 11610, 11420, 11435, 12337, 12528, 12925, 12935
Superscan 10864, 10093, 11944
Supersonic 11753, 12104, 12784, 13154, 13204, 13593, 13595, 13877, 13894
SVA 10748, 10865, 11963
Sylvania 11864, 11394, 11886, 10054, 10171, 11271, 11314, 11595, 11665, 11913, 11931, 11944, 11963
Symphonic 11394, 10171, 10180, 11595, 11904, 11913, 11944
Syntax 11610, 11144, 11240, 11331
TAG 13498
Tandy 10093
Tatung 11756, 11286
TCL 12434

Technics 10250, 10051
Technol Ace 10179
Techwood 10051
Teknika 10054, 10060, 10180, 10150, 10179, 10186
Telefunken 10702
Thomas America 11904
TMK 10178
TNCi 10017
Toshiba 11524, 11656, 10156, 11156, 11256, 11936, 12006, 10650, 10060, 10154, 11265, 11369, 11343, 11704, 11916, 11935, 11945, 11959, 12667, 12684
Toshinaer 13576
TruTech 11665, 11723, 12066
TVS 10463
US Logic 11286
Venturer 11865, 11868
Vidikron 10054, 11398
Vidtech 10178
Viewsonic 12049, 10864, 11755, 11564, 12087, 13706, 12839, 12745, 12277, 12111, 12014, 11742, 11627, 11578, 11542, 11365, 11330, 10885, 10857, 10797
Viore 11207, 11684, 11811, 12104, 12352, 13094, 13118, 13159, 13382
VisionQuest 13380
Vivitek 11369
VIZIO 11758, 13758, 12757, 10864, 11756, 10885
Vuon 13418
Wards 10156, 11156, 10054, 10178, 10060, 10047, 10154, 10017, 10051, 10180, 10179, 10186, 11347
Waycon 10156
Westinghouse 11712, 13470, 13579, 12397, 10451, 13949, 13908, 13382, 13094, 12499, 12293, 12195, 11577, 11300, 11282, 11217, 10890, 10885
White Westinghouse 10463, 11661, 10623
Wyse 11365
Yamaha 10797, 11576
Zenith 11423, 12358, 12731, 10178, 10047, 10017, 10463, 11265, 10145, 11661, 11365, 11904, 11911, 12612, 12742

3D TV (T)
Coby 13478
Dynex 12049
Elite 13867
Hisense 13519
LG 11423, 12731, 12424, 11265
Panasonic 11480, 11941
Sanyo 11142
Sceptre 12337
Sharp 12360, 13867
Toshiba 11524
VIZIO 11758, 13758

DLP (T)
Audiovox 11951
Durabrand 11665
Hewlett Packard 11494

iLo 11463
LG 11423, 11265
Mitsubishi 11250
NuVision 12158
Orion 11463
Panasonic 11480, 11291, 10650
Philips 11867
RCA 11447
Samsung 11060
Sansui 11463, 11892
Toshiba 11524, 11265
Viore 11811

LCD (T)

Acer 11339
Akai 11675, 11385, 11688, 11692, 11935, 12232
AOC 11589, 12087, 11365, 12014, 12402, 12621
Aomni 11623
Apex Digital 12397, 10890, 11217
Astar 11531
Asus 13340
Audiosonic 11675
Audiovox 11564, 10180, 13410, 13065, 12513, 12413, 12121, 11951, 11937, 11868, 11865, 11769, 11766, 11276, 10875, 10846, 10802
Auria 12087, 12277
BenQ 11315, 11562
Byd:sign 11311
Citizen 11672, 11935
Claris 13807
Coby 13478, 13646, 13627, 13493, 13202, 12560, 12348, 12344, 12340, 12338, 12326, 12315, 12314, 12306, 12017, 11634, 11538
Cornea 13677
Craig 13423
Crosley 13115
Curtis 12397, 12352, 12466, 12855, 12859, 13228, 13577, 13895
Dell 11264, 11863
Digital Lifestyles 11765, 11822
Dynex 12049, 12184
Electric Mirror 13166
Electrohome 11672
Electron 12855
Element 11886, 12183, 12964, 13559
Emerson 11864, 11394, 11886, 10171, 11963, 12183, 13559
Emprex 11422, 11765
Envision 11589, 12087, 11365, 12014
Epson 11122
Fluid 12964
Funai 10171
GFM 11864, 11886
GPX 10179, 12617, 12784, 13402
H & B 11366
Haier 11753, 11749, 11748, 12293, 12309, 12690, 13382
Hanns.G 11783
Hannspree 11348, 11351, 11352, 11745, 11783, 12786
Hewlett Packard 11642, 11494, 13126

Hidear 13817
Hisense 11314, 11660, 12183, 13519
Hitachi 11643, 11576, 12207, 12756
Hyundai 11219, 13418
iLo 11394, 11286, 11603, 11684, 11990, 13149
InFocus 11366
Initial 11603, 11990
Insignia 12049, 11564, 11204, 11517, 12002, 12184, 12417, 12751
iRIS 12189
iSymphony 13094, 13118, 13382
JCM 12189, 12256
Jensen 11299, 12541, 13204
JVC 11601, 12271, 11774, 11253, 11670, 12321, 13650, 13854
Kingston 13284
Klegg 11366
Kost 11483
Lasonic 13198
LG 11423, 12358, 12731, 12424, 12834, 10178, 11265, 12864
LodgingStar 13147
Magnavox 11455, 12372, 10802, 11012, 11198, 11365, 11944, 11990, 13292
Marantz 11454
Maxent 11755, 11714, 11757
MB Quart 11868
Memorex 10179, 11570, 11670, 11892, 12739
Mintek 11603, 11990
Mitsubishi 11250, 10150, 11797
Naxa 12104, 12735, 13154, 13382
NEC 11398, 11797, 12293, 13257
Nexus Electronics 12183
Norcent 11589, 11089, 11365, 11591, 11745
Norwood Micro 11286
NuVision 11657, 12158
Ölevia 11610, 11144, 11240, 11331
Optique 12189
Orion 13540
Panasonic 11480, 11291, 10650, 11941
PARK 12104, 12194, 12202
Philco 11394, 10171, 11963
Philips 11867, 11454, 11455, 11744, 12372, 10230, 11483, 11856, 13292, 13565
Pioneer 11260
Planar 11589
Polaroid 11523, 11498, 11276, 11314, 11316, 11538, 11762, 11766, 11767, 11769, 12121
Prima 11753, 11749
Proscan 12147, 12183, 12256, 13382, 13577
Pyle 12196, 12641
RCA 11447, 12434, 12746, 12932, 12187, 10047, 11781, 11868, 11958, 12183, 12855, 13382, 13577, 13938
RevolutionHD 11623
Sampo 11755
Samsung 10702, 10766, 10814, 11235, 12596, 12733, 12814
Sansui 11409, 11670, 11892, 11935,

13540, 13564
Sanyo 11142, 11362
Sceptre 10878, 11217, 11360, 11599, 12337, 12506, 12528
Scott 11711
Seiki 10178, 12964, 13559, 13560, 13953
Sens 11865
Sharp 12360, 10818, 10093, 11393, 12402
Sherwood 11399, 13061
Sigmac 13477
Silo Digital 13794
Skyworth 11799, 13253
Solé 11366, 11483, 11623
Sony 11317, 11685, 11786, 11791, 12736
Soyo 11520, 11826
SunBriteTV 11610, 11420, 11435, 12337, 12528, 12925, 12935
Superscan 10864
Supersonic 12104, 12784, 13154, 13204, 13593, 13595, 13877, 13894
SVA 11963
Sylvania 11864, 11394, 11886, 10171, 11271, 11314, 11963
Symphonic 11394, 10171, 11595
Syntax 11610, 11144, 11240, 11331
TAG 13498
Tatung 11286
TCL 12434
Toshiba 11524, 11656, 10156, 11256, 12006, 11343, 11935, 12667
Toshinaer 13576
TruTech 11723
US Logic 11286
Venturer 11865, 11868
Vidikron 11398
Viewsonic 12049, 10864, 11564, 12087, 10857, 10885, 11330, 11365, 11542, 11578, 11627, 11742, 12014, 12111, 12277, 12745
Viore 11684, 11811, 12104, 12352, 13094, 13118, 13159, 13382
VisionQuest 13380
Vivitek 11369
VIZIO 11758, 13758, 12757, 10864, 11756, 10885
Vuon 13418
Westinghouse 11712, 13470, 13579, 12397, 13949, 13908, 13382, 13094, 12499, 12293, 12195, 11577, 11300, 11282, 11217, 10890, 10885
Wyse 11365
Zenith 11423, 10178, 10017, 11265, 11365, 12612, 12742

TV/DVD Combination (T)

Advent 11570
Affinity 13717
Akai 11675, 11935, 12232
Apex Digital 10765, 11943
Audiovox 11766, 11865, 11868, 11937, 11951, 12413, 12513, 13065, 13410
Axion 11937
Broksonic 10463, 11935

Citizen 11935
Coby 11538, 12314, 12315, 12340, 12344, 12347, 12560, 13202, 13627
Curtis 12466, 12855, 13895
Durabrand 10171
Dynex 12049, 12184
Electrohome 11670
Emerson 11864, 11394, 11886, 11963
ESA 11963
Funai 11394, 11963
GFM 11963
GPX 12617, 12784
Haier 11753, 11749, 11748, 12309
Hisense 13519
Hitachi 12207, 12756
iLo 11990
Initial 11990
Insignia 12049, 11892, 11963, 12002, 12417, 12751
iSymphony 13094
JVC 12271, 11774, 11670, 13854
LG 11423
Magnavox 11454, 12372, 11944, 11963, 11990
Maxent 11714
Memorex 10463, 11670, 11911
Mintek 11603, 11990
Naxa 12104, 13382
Nimbro 12104
Panasonic 10051, 11924, 11927, 11941, 11947, 12654
Philco 11963
Philips 11454, 12372, 11394, 11961, 12740
Polaroid 11523, 11538, 11766, 11769, 12002
Power Acoustik 11865
Prima 11753
Proscan 12256
Pyle 12196
RCA 11447, 12746, 12932, 12187, 10047, 11868, 11958, 12002, 13382
Samsung 11903
Sansui 11670, 11935, 13564
Sceptre 12528
Sens 11865
Sharp 12360, 10818
Skyworth 11799, 13253
Supersonic 11753, 12104, 12784, 13593, 13595, 13877, 13894
Sylvania 11864, 11394, 11886, 10171, 11944, 11963
Symphonic 11595, 11944
Toshiba 11524, 11656, 11256, 12006, 11935, 12667, 12684
TruTech 12066
Venturer 11865, 11868
Viewsonic 12049, 10864
Viore 11811, 12104, 12352, 13094, 13118, 13382
VisionQuest 13380
Westinghouse 11712, 11300