

Setup Codes for Audio – Accessory (M)

ZVOX: 32332, 32334

Setup Codes for Satellite Set Top Box (S)

DIRECTV: 00001, 00002, 00003,
00004, 00005, 00006, 00007, 00008

Hughes Network Systems: 00001

Humax: 00001

Qwest: 00001

Samsung: 00001

SAT/PVR Combination (S)

DIRECTV 00001, 00002, 00003,
00004, 00005, 00006, 00007, 00008

Humax: 00001

Samsung: 00001

Setup Codes for Television (T)

Aaxa: 13634

Acer: 11339

Admiral: 10093, 10463, 10179

Advent: 11570

Affinity: 13577, 13716, 13717

Aiwa: 11362, 11916

Akai: 10702, 11675, 1065,

10672, 11207, 118385, 11688, 11690

Akura: 11498

Alaron: 10179

Albatron: 107000

America Action: 10180

Anam: 10180

AOC: 11589, 12087, 11089,
11365, 11590, 12014,
12402, 12621, 13707

Aomni: 11623

Apex Digital: 12397, 10748, 10765,
10890, 11217, 11943

Astar: 11531

Asus: 13340

Audiosonic: 11675

Audiovox: 11564, 10451, 10180,
13410, 13065, 12513,
12413, 12121, 11951,
11937, 11868, 11865,
11769, 11766, 11276,
10875, 10846, 10802,
10623

Auria: 12087, 12277

Aventura: 10171

Axion: 11937

Bang & Olufsen: 11620

Bell & Howard: 10154

BenQ: 11756, 11315, 11562

Berkshire: 10047

Bradford: 10180

Broksonice: 10463, 11911, 11935,
11938

Byd:sign: 11311

Candle: 10186

Carver: 10054

CCE: 10623

Celera: 10765

Champion: 11362

Changhong: 10765

Citizen: 10060, 10186, 11672,
11935

Clarion: 1080

Claris: 13807

Coby: 13478, 13646, 13629,
13627, 13493, 13202,
12560, 12348, 12347,
12344, 12340, 12338,
12326, 12315, 12314,
12306, 12017, 11634,
11538

Commercial Solutions: 11447, 10047

Conia: 11498

Contec: 10180

Contex: 13939, 14053, 14156

Cornea: 13677

Craig: 10180, 13423

Crosley: 10054, 13115

Crown: 10180

CTX: 10700

Curtis:	12397, 11326, 12352, 12466, 12855, 12859, 13228, 13577, 13636, 13895, 13939	Fujimaro:	11498
Curtis Mathes:	10702, 10054, 10093, 10060, 10047, 10154, 10145, 10451, 11661, 11347, 11959	Fujitsu:	10809, 10179, 10186, 10853
CXC:	10180	Fujitsu Siemens:	10809
Cytron:	11326	Funai:	11394, 10171, 10180, 1079, 11271, 11904, 11913, 11963
Daewoo:	10154, 10451, 11661, 10623, 10661, 10672, 13115	FutureTech:	10180
Dell:	11264, 11863	Gateway:	11756, 117566
Denon	10145	GE:	11447, 10178, 10047, 10051, 10451, 10765, 11347, 11547, 11917
Digital Lifestyles:	11765, 11892	GFM:	11864, 11886, 10171, 11665, 11963
Disney:	11665, 11892	Gilbralter:	10017
Dumont:	10017	GoldStar:	10178
Durabrand:	10178, 10171, 10463, 10180, 11463, 11570, 11595, 11665	GPX:	10179, 12617, 12784, 13402
Dynex:	12049, 11463, 12184	Grunpy:	10180, 10179
Electric Mirror:	13166	H&B:	11366
Electrograph:	11755, 11623	Haier:	11753, 11749, 11748, 11570, 12293, 12309, 12494, 12690, 13204, 13382
Electrohome:	10463, 11570, 11670, 11672	Hallmark:	10178
Electron:	12855	Hanns.G:	11783
Element:	11886, 12183, 12964, 13559	Hannspreet:	11348, 11351, 11352, 11745, 11783, 12786
Elite:	13867	Harley Davidson:	10179, 11904
Emerson:	11864, 11394, 11886, 10178, 10171, 10154, 10451, 10463, 10180, 11661, 11595, 11665, 10623, 10179, 11911, 11913, 11944, 11963, 12183, 13559	Harman/Kardon:	10054
Emprex:	11422, 11765	Harvard:	10180
Envision:	11589, 12087, 11365, 12014	Havermy:	10093
Epson:	11122	Helios:	10865
ESA:	10171, 11595, 11944, 11963	Hello Kitty:	10451
Fisher:	10154, 11362	Hewlett Packard:	11642, 11494, 11089, 13126
FireTV:	12434	Hidear:	13817
Fluid:	12964	Hisense:	10748, 11314, 11660, 12183, 13519
		Hitachi:	11643, 10145, 10679, 10797, 11484, 11576, 11904, 13149
		Hyundai:	11219, 13418
		iLo:	11394, 11463, 11286, 11603, 11665, 11684, 11990, 13149

Infinity:	10054	Mangavox:	11867, 11454, 11455,
InFocus:	11366		12597, 12372, 11755,
Initial:	11603		10054, 10171, 11051,
Insignia:	12049, 11423, 1156,		10706, 13292, 12492,
	10171, 10463, 12751,		10179, 11990, 11963,
	12432, 12417, 12184,		11944, 11931, 11913,
	12088, 12002, 11963,		11904, 10186, 11856,
	11892, 11660, 11641,		10230, 10802, 11365,
	11517, 11385, 11326,		11198, 11054, 11012
	11204	Marantz:	11454, 11054, 10704,
Inteq:	10017		11054, 11154, 11398,
iRIS:	12189		11714
iSymphony:	13094, 13118, 13382	Matsushita:	10250, 10650
JBL:	10054	Maxent:	11755, 11714, 11757
JCM:	12189, 12256	MB Quart:	11868
Jensen:	11299, 11362, 12541,	Megapower:	10700
	13204	Megatron:	10178, 10145
JVC:	11601, 12271, 12264,	Memorex:	10178, 10154, 10463,
	10650, 11774, 10463,		10150, 10179, 11570,
	10731, 11253, 11352,		11665, 11670, 11892,
	11670, 11923, 12321,		11903, 11911, 11924,
	13650, 13854		11927, 11938, 12739
KDS:	11498	MGA:	10178, 10150
KEC:	10180	Midland:	10047, 10017, 10051
Kingston:	13284	Mintek:	11603, 11990
Klegg:	11366	Mitsubishi:	11250, 10093, 10178,
KLH:	10765		10150, 11797, 11917
Konka:	11385	Monivision:	10700
Kost:	11483	Motoaola:	10093
KTV:	10180	MTC:	10060
Lasonic:	13198	Multitech:	10180
LG:	11423, 12358, 12731,	MX Onda:	11498
	12424, 128234, 10178	NAD:	10156, 11156, 10178
	10017, 11265, 10700,	Naxa:	12104, 12735, 13154,
	12612, 12865, 13941		13382
Lloyd's:	11094	NEC:	10704, 11398, 11704,
LodgingStar:	13147		11797, 12293, 13257
LXI:	10156, 10054, 10178,	NetTV:	11755
	10047, 10154	Nexus Electronics:	12183
MAG:	11498	Nikko:	10178
Magnasonic:	11913	Nimbro:	12104
		Norcent:	11589, 10748, 11089,
			11365, 11590, 11591,
			11745
		Norwood Micro:	11286
		NuVision:	11657, 12158

Olevia:	11610, 11144, 11240, 11311	Prism:	100551
ONN:	12434, 11756	Proscan:	11447, 10047, 11347, 12147, 12183, 12256, 13382, 13577, 13717
Onwa:	10180	Proton:	10178
Optimus:	10250, 10650, 10154, 11913, 11924, 11927	Proview:	11498
Optique:	12189	Pulsar:	10017
Optoma:	11348	Pyle:	12196, 12641
Optonica:	10093	Quasar:	10250, 11291, 10650, 11051, 11924, 11927
Orion:	10463, 11463, 10179, 11911, 11938, 13540	Radioshack:	10178, 10047, 10154, 10180, 11904
Otic:	11498	RCA:	11447, 12434, 12746, 12932, 12187, 10093, 10047, 10051, 11661, 13938, 13717, 13577, 13382, 13147, 12855, 12183, 12002, 11959, 11958, 11917, 11868, 11781, 11547, 11385
Panasonic:	11480, 10250, 11291, 12264, 10650, 10051, 11271, 11924, 11927, 1941, 11946, 11947, 12240, 12654	Realistic:	11347, 10679, 10090
PARK:	11376, 12104, 12194, 12202	RevolutionHD:	10178, 10154, 10180
Penney:	10156, 10178, 10060, 10047, 10051, 11347	Runco:	11623
Philco:	11394, 10054, 10171, 10179, 11271, 11665, 11963	Sampo:	10017, 11398
Philips:	11867, 11454, 11455, 11744, 12597, 12372, 11394, 10054, 10171, 13565, 13292, 12740, 12665, 12652, 12492, 11990, 11961, 11944, 11856, 11483, 11365, 11154, 11054, 11012, 10230	Samsung:	10702, 10650, 10178, 10060, 10766, 10814, 11060, 11235, 11267, 11903, 11959, 12596, 12733, 12814
Pioneer:	11457, 10679, 11260, 11398, 12240, 13254	Sansui:	10171, 10463, 11463, 11409, 11670, 11892, 11904, 11911, 11935, 11938, 13540, 13564
Planar:	11589	Sanyo:	10706, 10799, 11756, 10893, 10885, 12049, 12434, 11142, 10054, 10154, 10088, 11362
Polaroid:	11523, 11498, 10765, 11276, 11286, 11314, 11316, 11326, 11385, 10865, 11538, 11762, 11766, 11767, 11769, 11826, 12002, 12121	Sceptre:	10878, 11217, 11360, 11599, 12337, 12506, 12528
Portland:	10451, 11661	Scotch:	10178
Power Acoustik:	11865	Scott:	10178, 10180, 10179, 11711
Prima:	11753, 11749		
Princeton:	10700		

Sears:	10156, 10054, 10179, 11711, 10171, 10154, 10179, 11904	TAG:	13498
Seiki:	10178, 12964, 13559, 13560, 13953	Tandy:	10093
Seleco:	11351	Tatung:	11756, 11286
Sens:	11865	TCL:	12434
Sharp:	12360, 10818, 10093, 11393, 11917, 12402, 13867	Technics:	10250, 10051
Sheng China:	10093	Technol Ace:	10179
Sherwood:	11399, 13061	Techwood:	10051
Sigmac:	13423, 13477	Teknika:	10054, 10060, 10180, 10150, 10179, 10186
Signature:	10054	Telefunken:	10702
Silo Digital:	13794	Thomas America:	11904
Simpson:	10186	TMK:	10178
Skyworth:	11799, 13253	TNCi:	10017
Sole:	11366, 11483m 11623	Toshiba:	11524, 11656, 10156, 11156, 11256, 11936, 12006, 10650, 10060, 10154, 11265, 11369, 11343, 11704, 11916, 11935, 11945, 11959, 12667, 12684
Sony:	11300, 11317, 11685, 11786, 11791, 11904, 12736	Toshinaer:	13576
Soundesign:	10178, 10180, 10179, 10186	TruTeeh:	11665, 11723, 12066
Soyo:	1152, 11826	TVS:	10463
Spectroniq:	11498	US Logic:	11286
Squareview:	10171	Venturer:	11865, 11868
SSS:	10180	Vidikron:	10054, 11398
Starlite:	10180	Vidtech:	10178
SunBriteTV:	11610, 11420, 11435, 12337, 12528, 12925, 12935	Viewsonic:	12049, 10864, 11755, 11564, 12087, 13706, 12839, 12745, 12277, 12111, 12014, 11742, 11627, 11578, 11542, 11365, 11330, 10885, 10857, 10797
Superscan:	10864, 10093, 11944	Viore:	11207, 11684, 11811, 12104, 12352, 13094, 13118, 13159, 11382
Supersonic:	11753, 12104, 12784, 13154, 13204, 13593, 13595, 13877, 13894	VisionQuest:	13380
SVA:	10748, 10865, 11963	Vivitek:	11369
Sylvania:	11864, 11394, 11886, 10054, 10171, 11271, 11314, 11595, 11665, 11913, 11931, 11944, 11961	VIZIO:	11758, 13758, 12757, 10864, 11756, 10885
Symphonic:	11394, 10171, 10180, 11595, 11904, 11913, 11944	Vuon:	13418
Syntax:	11610, 11144, 11240, 11311		

Wards:	10156, 11156, 10054, 10178, 10060, 10047, 10154, 10017, 10051, 10180, 10179, 10186, 11347
Waycon:	10156
Westinghouse:	11712, 13470, 13579, 12397, 10451, 13949, 13908, 13382, 13094, 12499, 12293, 12195, 11577, 11300, 11282, 11217, 10890, 10885
White Westinghouse:	10890, 10885
Wyse:	11365
Yamaha:	10797, 11576
Zenith:	11423, 12358, 12731, 10178, 10047, 10017, 10463, 11265, 10145, 11661, 11365, 11904, 11911, 12612, 12742

Setup Codes for 3D TV (T)

Coby:	13478
Dynex:	12049
Elite:	13867
Hisense:	13519
LG:	11423, 12731, 12424, 11265
Panasonic:	11480, 11941
Sanyo:	11142
Sceptre:	12337
Sharp:	12360, 13867
Toshiba:	11524
VIZIO:	11758

Setup Codes for DLT (T)

Audiovox:	11951
Durabrand:	11665
Hewlett Packard:	11494
iLo:	11463
LG:	11423, 11265
Mitsubishi:	11250
NuVision:	12158
Orion:	11463
Panasonic:	11480, 11291, 10650

Philips:	11867
RCA:	11447
Samsung:	11060
Sansui:	11463, 11892
Toshiba:	11524, 11265
Viore:	11811

Setup Codes for LCD (T)

Acer:	11339
Akai:	11675, 111385, 11688, 11692, 11935, 12232
AOC:	11589, 12087, 11365, 12014, 12402, 12621,
Aomni:	11623
Apex Digital:	12397, 10890, 11217
Astar:	11531
Asus:	13340
Audiosonic:	11675
Audiovox:	11564, 10180, 13410, 13065, 12513, 12413, 12121, 11951, 11937, 11868, 11865, 11769, 11766, 11276, 10875, 10846, 10802
Auria:	12087, 12277
BenQ:	11315, 11562
Byd:sign:	11311
Citizen:	11672, 11935
Claris:	13807
Coby:	13478, 16464, 13627, 13493, 13202, 12560, 12348, 12344, 12340, 12338, 12326, 12315, 12314, 12306, 12017, 11634, 11538
Cornea:	13677
Craig:	13423
Crosley:	13115
Curtis:	12397, 12352, 12466, 12855, 12859, 13228, 13577, 13895
Dell:	11264, 11863
Digital Lifestyles:	11765, 11822
Dynex:	12049, 12184
Electric Mirror:	13166
Electrohome:	11672

Electron:	12855	LG:	11423, 12358, 12731,
Element:	11886, 12183, 12964,		12424, 12834, 10187,
	13559		11265, 12864
Emerson:	11864, 11394, 11886,	LodgingStar:	13147
	10171, 11963, 12183,	Magnavox:	11455, 12372, 10802,
	13559		11012, 11198, 11365,
Emprex:	11422, 11765		11944, 11990, 13292
Envision:	11589, 12087, 11365,	Marantz:	11454
	12014	Maxent:	11755, 11714, 11757
Epson:	11122	MB Quart:	11868
Fluid:	12964	Memorex:	10179, 11570, 11670,
Funai:	10171		11892, 12739
GFM:	11864, 11886	Mintek:	11603, 11990
GPX:	10179, 12617, 12784,	Mitsubishi:	11250, 10150, 11797
	13402	Naxa:	12104, 12735, 13154,
H & B:	11366		13382
Haier:	11753, 11749, 11748,	NEC:	11398, 11797, 12293,
	12293, 12309, 12690,		13257
	13382	Nexus Electronics:	12183
Hanns. G:	11783	Norcent:	11589, 11089, 11365,
Hannsprece:	11348, 11351, 11352,		11591, 11745
	11745, 11783, 12786	Norwood Mirco:	11286
Hewlett Packard:	11642, 11494, 13126	NuVision:	11657, 12158
Hidear:	13817	Olevia:	11610, 11144, 11240,
Hisense:	11314, 11660, 12183,		11331
	13519	Optique:	12189
Hitachi:	11643, 11576, 12207,	Orion:	13540
	12756	Panasonic:	11480, 11291, 10650,
Hyundai:	11219, 13418		11941
iLo:	11394, 11286, 11603,	PARK:	12104, 12194, 12202
	11684, 11990, 13149	Philco:	11394, 10171, 11963
InFocus:	11366	Philips:	11867, 11454, 11455,
Initial:	11603, 11990		11744, 12372, 10230,
Insignia:	12049, 11564, 11204,		11483, 11856, 13292,
	11517, 12002, 12184, 12417, 12754		13565
iRIS:	12189	Pioneer:	11260
iSymphony:	13094, 13118, 13382	Planar:	11589
JCM:	12189, 12256	Polaroid:	11523, 11498, 11276,
Jensen:	11299, 12541, 13204		11314, 11316, 11538,
JVC:	11601, 12271, 11774,		11762, 11766
	11253, 11670, 12321, 13650, 13854	Prima:	11767, 11769, 12121
Kingston:	13284	Proscan:	11753, 11749, 12256,
Klegg:	11366		13382, 13577
Kost:	11483	Pyle:	12196, 12641
L,asonic:	13198		

RCA:	11447, 12434, 12746, 12932, 12187, 10047, 11781, 11868, 1958, 12183, 12855, 13382, 135767, 13938	TCL:	12434
RevolutionHD:	11623	Toshina:	11524, 11656, 10156, 11256, 12006, 11343, 11935, 12667
Sampo:	11755	Toshinaer:	13576
Samsung:	10702, 10766, 10814, 11235, 12596, 12733, 12814	TruTech:	11723
Sansui:	11409, 11670, 11892, 11935, 13540, 13564	US Logic:	11286
Sanyo:	11142, 11362	Venturer:	11865, 11868
Sceptre:	10878 11217, 11360, 11599, 12337, 12506, 12528	Vidikron:	11398
Scott:	11711	Viewsonic:	12049, 10864, 11564, 12087, 10857, 10885, 11330, 11365, 11542, 11578, 11627, 11742, 12014, 12111, 12277, 12745
Seiki:	10178, 12964, 13559, 13560, 13953	Viore:	11684, 11811, 12104, 12352, 13094, 13118, 13159, 13382
Sens:	11865	VisionQuest:	13380
Sharp:	12360, 10818, 10093, 11393, 12402	Vivitek:	11369
Sherwood:	11399, 13061	VIZIO:	11758, 13758, 12757, 10864, 11756, 10885
Sigmac:	13477	Vuon:	13418
Silo Digital:	13794	Westinghouse:	11712, 13470, 13579, 12397, 13949, 13908, 13382, 13094, 12499, 12293, 12195, 11577, 11300, 11282, 11217, 10890, 10885
Skyworth:	11799, 13253	Wyse:	11365
Sole:	11366, 11483, 11623	Zenith:	11423, 10178, 10017, 11265, 11365, 12612, 12742
Sony:	11317, 11685, 11786, 11791, 12736		
Soyo:	11520, 11826		
SunBriteTV:	11610, 11420, 11435, 12337, 12528, 12925, 12935		
Superscan:	10864		
Supersonic:	12104, 12784, 13154, 13204, 13593, 13595, 13877, 13894		
SVA:	11963		
Sylvania:	11864, 11394, 11886, 10171, 11271, 11314, 11963		
Symphonic:	11394, 10171, 11595		
Syntax:	11610, 11144, 11240, 11331		
TAG:	13498		
Tatung:	11286		

Setup Codes for TV/DVD Combinations (T)

Advent:	11570
Affinity:	13717
Akai:	11675, 11935, 12232
Apex Digital:	10765, 11943
Audiovox:	11766, 11865, 11868, 11937, 11951, 12413, 12513, 13065, 13410
Axion:	11937
Broksonic:	10463, 11935
Citizen:	11935

Coby:	11538, 12314, 12315, 12340, 12344, 12347, 12560, 13202, 13627	Samsung:	11903
Curtis:	12466, 12855, 13895	Sansui:	11670, 11935, 13564
Duraband:	10171	Sceptre:	12528
Dynex:	12049, 12184	Sens:	11865
Electrohome:	11670	Sharp:	12360, 10818
Emerson:	11864, 11394, 11886, 11963	Skyworth:	11799, 13253
ESA:	11963	Supersonic:	11753, 12104, 12784, 13593, 13595, 13877, 13894
Funai:	11394, 11963	Sylvania:	11864, 11394, 11886, 10171, 11944, 11963
GFM:	11963	Symphonic:	11595, 11944
GPX:	12617, 12784	Toshiba:	11524, 11656, 11256, 12006, 11935, 12667, 12684
Haier:	11753, 11749, 11748, 12309	TruTech:	12066
Hisense:	13519	Venturer:	11865, 11868
Hitachi:	12207, 12756	Viewsonic:	12049, 10864
iLo:	11990	Viore:	11811, 12104, 12352, 13094, 13118, 13382
Initial:	11990	VisionQuest:	13380
Insignia:	12049, 11892, 12963, 12002, 12417, 12751	Westinghouse:	11712, 11300
iSymphony:	13094		
JVC:	12271 11774, 11670, 13854		
LG:	11423		
Mangavox:	11454, 12372, 11944, 11963, 11990		
Maxent:	11714		
Memorex:	10463, 11670, 11911		
Mintek:	11603, 11990		
Naxa:	12104, 13382		
Nimbro:	12104		
Panasonic:	10051, 11924, 11927, 11941, 11947, 12654		
Philco:	11963		
Philips:	11454, 12372, 11394, 11961, 12740		
Polaroid:	11523, 11538, 11766, 11769, 12002		
Power Acoustik:	11865		
Prima:	11753		
Proscan:	12256		
Pyle:	12196		
RCA:	11447, 12746, 12932, 12187, 10047, 11868, 11958, 12002, 13382		